

Installation instructions: RLD

Rear Light Dongle

using the example of a R 1250 GS



The set always consists of two RLD modules and is perfectly matched to your motorcycle to ensure easy installation and optimum function.

Installation is extremely simple and can be completed in just a few minutes: The RLD modules are plugged between the rear blinker plugs of your BMW motorcycle and are ready for immediate use.

If you are not sure where the respective plug connections are located on your model or if you have any questions, please contact us for model-specific assistance at nachruestungen@emotion-ride.de or **+49 2206 9198041**.

Installation:

The indicator plugs are located under the pillion seat on these models.

1. Disconnect the original plug connections of the rear indicator plugs and insert the respective RLD module on each side between the original plug connection that has just been disconnected. Stow the modules in the area of the plug connections.
2. Carry out a function test by switching on the ignition and activating the direction indicators on both sides.



General information:

Opening a module immediately voids the warranty.

After working on your motorcycle's lighting system, always make sure that the lighting and signaling system is working properly.

If you are not sure where the corresponding plug connections are located on your model or if you have any questions, please contact us for model-specific assistance at nachruestungen@emotion-ride.de or **+49 2206 9198041**. If in doubt, contact a motorcycle workshop in your region for assistance with installation.

If there are any problems with the function of the module or the associated components, please contact us at nachruestungen@emotion-ride.de or **+49 2206 9198041**.

Scope of delivery when ordering a RLD:

Description	Quantity
Rear Light Dongle	2

